

EMP P/N - 10991

2010-2017 Can-Am Commander Front Skid Plate

Includes:

1. (4) 5/16 x 1" Self-Tapping Torx Screw
2. (4) 3/8 x 1" Flange Head Bolts
3. (4) 3/8" Flat Washers
4. (4) 3/8" Nyloc Nuts

Installation:

1. Set parking brake.
2. Drill out four holes in the front with a .390" drill bit.
3. Install the four 3/8" bolts, washers & nuts and tighten.
4. Drill four .265" holes in the bottom for the Self-Tapping Torx Screws & install screws.
5. Your installation is complete.



www.ExtremeMetalProducts.com

EMP P/N - 10991

2010-2017 Can-Am Commander Front Skid Plate

Includes:

1. (4) 5/16 x 1" Self-Tapping Torx Screw
2. (4) 3/8 x 1" Flange Head Bolts
3. (4) 3/8" Flat Washers
4. (4) 3/8" Nyloc Nuts

Installation:

1. Set parking brake.
2. Drill out four holes in the front with a .390" drill bit.
3. Install the four 3/8" bolts, washers & nuts and tighten.
4. Drill four .265" holes in the bottom for the Self-Tapping Torx Screws & install screws.
5. Your installation is complete.



www.ExtremeMetalProducts.com

EMP P/N - 10991

2010-2017 Can-Am Commander Front Skid Plate

Includes:

1. (4) 5/16 x 1" Self-Tapping Torx Screw
2. (4) 3/8 x 1" Flange Head Bolts
3. (4) 3/8" Flat Washers
4. (4) 3/8" Nyloc Nuts

Installation:

1. Set parking brake.
2. Drill out four holes in the front with a .390" drill bit.
3. Install the four 3/8" bolts, washers & nuts and tighten.
4. Drill four .265" holes in the bottom for the Self-Tapping Torx Screws & install screws.
5. Your installation is complete.



www.ExtremeMetalProducts.com

EMP P/N - 10991

2010-2017 Can-Am Commander Front Skid Plate

Includes:

1. (4) 5/16 x 1" Self-Tapping Torx Screw
2. (4) 3/8 x 1" Flange Head Bolts
3. (4) 3/8" Flat Washers
4. (4) 3/8" Nyloc Nuts

Installation:

1. Set parking brake.
2. Drill out four holes in the front with a .390" drill bit.
3. Install the four 3/8" bolts, washers & nuts and tighten.
4. Drill four .265" holes in the bottom for the Self-Tapping Torx Screws & install screws.
5. Your installation is complete.



www.ExtremeMetalProducts.com