



POLARIS® AZA® XP1000

2014-2016 POLARIS® AZA® XP1000

**DOME LIGHT MOUNT
INSTALLATION INSTRUCTIONS
FITS (2) A-SERIES®**

*Lights sold separately



KIT INCLUDES

- | | |
|--------------------------|--------------------------------------|
| (1) 2-Piece Mount #46522 | (4) M6 x 12mm long SS Pan Head Bolts |
| (4) M6 SS Nyloc Nuts | (2) Rubber Grommets |

IMPORTANT

Thank you for purchasing Rigid Industries® products for your Polaris®. Installation is fairly simple with the right tools and good mechanical abilities. If you are not confident in your mechanical skills, please seek the help of a professional to perform the installation. Please read through all of these instructions and tips before proceeding with the installation. **It is strongly recommended that this product be installed by a professional.**

STEP 1

Remove and save (1) 15mm bolt.
See Figure 1.



Figure 1

STEP 2

Place Rigid Industries mount on cage and re-install bolt saved from Step 1.
See Figure 2.



Figure 2

Always disconnect any power sources connected to your vehicle before servicing fuses or electrical systems.

STEP 3

Install (1) rubber grommet in wiring hole, (2) M6 x 12mm long SS Pan Head Bolts, and (2) M6 SS Nyloc nuts. See Figure 3.



Figure 3

STEP 4

Repeat Steps 1 – 3 for remaining side.

Wire your lights according to the instructions included with the light. Take care to avoid any heat sources and sharp or abrasive surfaces.

**Your installation is now complete.
Welcome to the Rigid Nation!**



WARRANTY INFORMATION

For warranty information, visit www.rigidindustries.com/about/warranty

Follow us on facebook at
[Facebook.com/RigidIndustries](https://www.facebook.com/RigidIndustries)

779 N Colorado St, Gilbert, AZ 85233 • 855-760-5337 • www.rigidindustries.com

PKG-IS-157-B

Rigid Industries, Rigid and A-Series are registered and/or common law marks owned by JST Performance, LLC, a Delaware limited liability company d/b/a Rigid Industries.