



85630 – 3 – Way Hitch

No.	Description	Quantity
1	Drawbar	1
2	$\frac{3}{4}$ " x 1.75" Hex Head Bolt	1
3	$\frac{3}{4}$ " Nut	1
4	$\frac{3}{4}$ " Star Washer	1
5	$\frac{3}{4}$ " Lock Washer	1



KOLPIN HITCH



OEM HITCH



Hitch Mounting:

1. Place the hitch on the OEM Ball Mount of your ATV.
2. Place the Star Washer between the Kolpin Hitch and the OEM Ball Mount.
3. Insert the $\frac{3}{4}$ " Hex Head Bolt through the hitches.
4. Next, slide on the $\frac{3}{4}$ " Lock Washer Provided, and the $\frac{3}{4}$ " Nut. Tighten Securely! See order above for correct attachment!
5. The larger diameter hole is for a standard shank hitch ball. The smaller diameter hole is for a clevis attachment.

Kolpin Outdoors, Inc.
 205 N. Depot St, Fox Lake, WI 53933
 Phone #: (877) 9KOLPIN or (920) 928-3118
www.kolpin.com
customerservice@kolpin.com