# **Chisel Plow/Scarifier**

# Product Instructions | Part No: 86100

#### Application: Verify accessory fitment at Kolpin.com.

**Before You Begin:** Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

*Note: If any hardware is missing, do not return to the store. Call us to help, Toll Free 1-877-956-5746.* 

### **Tools Required:**

• Standard Wrench Set or Adjustable Wrench Set

Assembly Time: Approximately 15 minutes

**Important:** Your Kolpin Chisel plow Kit is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

## Installation Instructions:

- Slide the six Brackets (item #2) onto the Kolpin Toolbar (not supplied in kit), as shown in the picture. Fasten the brackets using the six Bolts (item #3), Locknuts (item #4), and Washers (item #5) provided. Place three brackets on one side of the vertical tube on the Kolpin Toolbar. Place the other three brackets on the other side.
- 2. Leave enough room so that you are able to slide the Toolbar draw pins on and off of the lift arms of the Kolpin 3-Point Hitch unit.
- 3. Once you have your spacing correct, tighten securely.
- 4. Drop the Chisel Plow/Scarifer Blade through the vertical slot in the bracket. You will notice that the blade comes with a series of holes. The lowest hole is for transporting the blade. The other holes in the blade are there for a quick adjustment of different depths.
- 5. Final set up should look similar to the picture.



#### This Kit includes:

ltem	Qty	Part Description
1	6	Scarifer Blade, Painted
2	6	Scarifer Bracket, Painted
3	6	Hex Bolt, Zinc Plated, 1/2"-13 x 3-1/2" LG
4	6	Locknut, Zinc Plated, 1/2"-13
5	6	Flat Washer, Zinc Plated, 1/2"
6	6	Bent Hitch Pin, Zinc Plated, 5/8" x 3"
7	6	R-Pin, Zinc Plated, 1/2" Dia x 2" LG



Kolpin Outdoors, Inc. | 9955 59th Ave N | Plymouth, MN 55442 (877) 956-5746 or (763) 478-5800 | <u>www.kolpin.com</u> | <u>customerservice@kolpin.com</u>

#### **One Year Limited Warranty**

For the period of one (1) year from the purchase date, Kolpin will replace for the original purchaser, free of charge, any part or parts found upon examination by Kolpin to be defective in material, workmanship, or both.

All transportation costs incurred submitting product to Kolpin for warranty consideration must be borne by the purchaser. If Kolpin determines that the product must be returned to the factory for credit, please call 1-877-956-5746 for a Return Merchandise Authorization (RMA) number and shipping instructions.

This warranty does not apply to parts that have been damaged by accident, alteration, abuse, improper maintenance, normal wear, or other causes beyond the manufacturer's control. In order to protect you and your ATV, certain parts of the accessory system and/or hardware are designed to fail when the equipment is over-stressed. Parts that are lost due to loosening and improper maintenance are not covered under warranty. This warranty does not cover removal or reinstallation labor fees of the plow system and related components.

Peripheral products such as engines, electric motors, and actuators may carry an original manufacturer's warranty. Most hardware is general in nature and is easily obtained locally. Be sure to replace with minimum metric class 8.8 specification.

REV 03