






Defender Rear Bumper, Polaris RZR® RS1 Instructions

Installation

1. Locate the holes on the RS1's frame. *(See Figure #1)*
2. Jack up the **Rear Of The Vehicle** to remove the weight of the rear wheels.
NOTE: You may find it easier to remove the rear tires during this process.
- 3 Remove the **Stock Radius Rod Plate**.
4. Install the **HMF Defender Rear Bumper** making sure to align all the **Bolts Holes**. Start the bolts through the **Lower Bumper Bracket** using the stock nuts and bolts. **DO NOT TIGHTEN BOLTS.** *(See Figure #2)*
7. Install the supplied hardware into the **Top Brackets DO NOT TIGHTEN.**
8. Be sure the bumper is square then tighten the bolts starting with the **Radius Rods First** then the **Top Bracket Bolts.**

Hardware

-  (4) 1/4" Flat Washers
-  (2) M8-1.25 Nylock
-  (2) M8-1.25 X 20 Hex

* Click thumbnails to enlarge

Figure #1



Figure #2



(4) 1/4" Flat Washers



(2) M8-1.25 Nylock



(2) M8-1.25 X 20 Hex

