

# Installation Guide for P/N 945

- A-** 2) 1/4"-20 x 2.5" Hex Flange Bolts  
2) #700-13 Spacers (1 3/8" long)

*Uses pre-threaded holes*

- B-** 2) 1/4"-20 x 2.5" Hex Flange Bolts  
2) 1/4" HD Flat Washers  
2) #FJ-4 Spacers (1 9/16" long)  
2) 1/4" Nylock Nuts

*Use nut and washer on back side of unthreaded hole*

- C-** 2) 8 x 30mm Button Head Bolts  
2) 8mm Flat Washers  
2) #700-06 Nut Plates  
2) #700-68 Spacers (3/16" long)

*Mount to #700-06 nut plates braced behind steel plate welded to the frame  
If mounting in conjunction with our skid plates do not use spacers,  
bumper will overlap the skid plate and use the same mounts.  
If mounting bumper without our skid plate use #700-68 spacers to fill the gap*

