



CAN-AM COMMANDER HORN KIT

Thank you for purchasing XTC Power Products Horn Kit. It includes a Horn, Lit Horn Switch and Harness.

1. **Install Horn** – In the front near the passenger headlight, remove the bolt for the front support bracket and install the horn as shown.



2. Next to the Key Switch is a position to install a switch. Drill a hole in each corner, carefully cut out using a sharp cutter or Dremel tool. Run the Eight Pin Connector from the Switch Harness through the opening, attach to the switch and install into opening.



3. **Run power wire** – **Run power wire** – **MAKE SURE THE BATTERY IS DISCONNECTED** - run the horn power wires up to the OEM busbar under the dash. Remove the red protective cover, attach the ring terminal with the Red Wire to the left Keyed Power Post and the Ground to the Right Ground Post, do not connect to the center full time Power Post. Re-install protective cover.



4. Run the Harness- Above the brake pedal and behind the power steering box run the violet and black wire through the rubber grommet shown below in center photo and attach to the horn terminals.



5. Hook Battery back up.
6. Verify operation of Horn. Turn Key on and the Bottom Switch LED should illuminate, Push the top of the Horn Rocker and the Horn should sound.
7. Cable tie any extra harness under dash
8. Reinstall any removed parts.

We can be reached at Support@xtcpowerproducts.com.

Please visit our website at www.xtcpowerproducts.com

XTC Power Products
A Division of XTC Motorsports LLC
380 E Comstock Dr
Chandler, AZ 85225
480-558-8588

www.xtcpowerproducts.com

Copyright © 2024 XTC Motorsports LLC, All Rights Reserved