



Kawasaki KRX Cargo Box

JC11130_KRX

INSTALLATION INSTRUCTIONS

Parts Included

Part #	Qty.	Item
1	1	HIGHLANDS JC11130_KRX Cargo Box
2	2	M6 Bolt
3	2	M6 Washer

INSTALLATION INSTRUCTIONS

1. Remove the two M6 bolts from your machine's bed.
2. Install the box into the bed of the machine. Thread the two M6 bolts and fender washers provided through the box and into the threaded holes in the bed of the machine.
3. Tighten fully to secure the box in place.

