



Kawasaki H2 Glass Windshield Instructions

SKU: MA-KH2-WS-GLS-BLK-Y Fits: 2026 Kawasaki Teryx H2

Hardware	
Qty	Part
2	2 inch Billet Clamp
2	1/4-20 X 2" Button Head Bolt
2	1/4-20 X .75" Button Head Bolt
2	1/4-20 X .5 Button Head Bolt
2	1/4-20 Nylock Nut
6	10-24 X .5 Button Head Bolt
6	10-24 Nylock Nut
8	1/4 Flat Washer
4	1/4 Split Lock Washer
100 in	1/8" X .5" Adhesive foam



Adhesive foam is included to go along the bottom edge of the windshield (back side), and along top edge (back side) of the top plate. This may have been installed before shipping. If not, install this before installing windshield on UTV.

Step 1. Assemble top plate onto top of main windshield frame using the smaller bolts and nuts. Install hardware with the nut on the back of the windshield. No washers are used on these bolts and nuts.

Step 2. Remove the 4 front roof bolts on the factory roof. The roof will need to be propped up a few inches to install the windshield.

Step 3. Place the billet clamps on the roll cage as shown with the threaded hump facing up/forward and the holes toward the center of UTV. Loosely install the 2" long bolts with flat washer and lock washer from the back of the clamp. These will be tightened later

Step 4. Carefully lift the windshield and place it in position on the UTV. Be careful not to hit the painted plastics as it could scratch them.

Use two of the .75" long bolts with flat washers and locknuts on the top two holes. These will line up with holes in the factory cage gusset plates. Leave these bolts a little loose.



Adjust the position of the lower billet clamps to align with the holes on the windshield. When lined up, install the .5" long bolts with flat washer and lock washer thru the windshield and into the clamps.

With clamps and upper mounting bolts still loose, lift windshield upward about .125-.25 inches for optimal position. While being held in position, tighten lower clamp bolts to secure in place. Then tighten upper bolts.

Re-install roof bolts. Installation complete.