

Polaris RZR Pro XP & Turbo R *RPM* Big Fatty

Tools Needed:

- Soap & Water

Kit Components:

1	Big Fatty Intake Tube
1	102-110 T-Bolt Clamp
1	89-97 T-Bolt Clamp



Install Instructions:

1. Loosen upper and lower intake boot clamps.
2. Once loose, pull down from the bed, and away from the intake box. Your old stock intake boot should now be loose and can be removed.
3. Place the stainless steel T-Bolt Clamps supplied on the silicone intake.
4. Using soap and water, lightly wet the inside of the new RPM SxS silicone intake boot where it will be meeting the plastic to the air intake box, and bed intake. This will allow for an easy smooth install.
5. Push the silicone onto the air box and beds box intake firmly until seated. At this time you will position the boot away from the shock while tightening the clamps.
6. A set of helping hands is best, otherwise use cardboard or a rag to hold the intake away from the shock as you tighten the T-Bolt clamps. The T-Bolt clamps should be approximately $\frac{1}{8}$ " from the edge of the silicone and should be tightened until the silicone can not be moved, and slightly "mushing" appears on either side of the silicone.

