



YAMAHA® WOLVERINE X2™ REAR WINDJAMMER

Installation Instructions: Rear windjammer is designed as an easy to install one piece unit requiring no tools.

1. **Raise bed.**
2. **Position windjammer against roll cage attaching straps along the top of windjammer to roll cage.**
3. **Work down each side of windjammer attaching straps around roll cage.**
4. **When cover is level and positioned properly tighten all straps and attach Velcro along bottom of windjammer if desired.**
5. **Make sure no part of windjammer is against any heat source.**

**Remove completely prior to transporting on highways, where speeds may exceed 75 mph for extended periods of time

**Use mild soap and water only to clean all surfaces

Your new cover is guaranteed against any defects in material and workmanship for 1 year from the date of purchase. Should any problems arise, please contact your dealer. No warranty card is necessary.



Your UTV has several warning and caution labels around the machine that may be covered when this cover is installed. It is your responsibility as the UTV owner to read and understand these warnings as well as making sure anyone who operates the UTV is aware of the proper operation.