

X3/MAX Sport Front Bumper Instructions (CA162P360)

NOTE: Prior to installation, please verify if a revised version of this instruction sheet is available on proarmor.com.



Remove 4 (T30) bolts securing the front stock plastic cover. Drill out the 4 rivets to remove the cover. The cover and (2) T30 Bolts will not be reused.



Using (2) screws removed from step 1, tighten lower bumper to chassis.



Using the provided bracket included with the hardware, apply rubber strip to bracket and hand tighten the bracket to the bumper using (2) provided screws.



Insert and tighten (2) provided screws to secure upper plate to bumper as shown. To complete install of your Sport front bumper, torque down all installed bolts.







• **Never** stick hands, head or arms outside of vehicle at any time when it is in motion.

- **Always** wear and use proper safety equipment when using any Pro Armor product.
- Improper use of directions and/or product can result in injury to yourself or damage to your vehicle.
- **Disclaimer please read:** This product is sold without warranty expressed or implied. No warranty or representation is made as to the products ability to protect the user / occupant from any injury or death in any manner of use. The user assumes that risk. The effectiveness of this equipment is directly related to the manner in which it is installed, used, and / or maintained.
- Proper installation is solely the responsibility of the installer, and will not be assumed by Pro Armor.
- If you have questions about your installation or are unable able to complete installation, contact Pro Armor Customer Service (888)312-7667 or have an authorized dealer or trained technician, inspect your installation.

Pro Armor

1123 Sherborn St. Corona, Ca. 92879 | 888.312.7667 | www [For further information on installation instructions and warnings please visit our website]

| www.proarmor.com