

CMM Bronco Hard Top Panel Ball Mount

Thank you for purchasing the CMM Bronco Hard Top Panel Ball Mount

You will need: T-40 Torx

8mm Allen Wrench

1. Use your T-40 Torx to take out the factory freedom panel lever bolt.
2. Install CMM Ball bolt with 8mm Allen Wrench.
3. Attach desired device with 1' ball mount accessory.

