

Over Armour Offroad

2515 Bypass Rd. Flemingsburg, KY 41041
606-845-7439

Instructions for Installation and Care of
2002-2008 Polaris Ranger
Folding Lexan Windshield
PO-08RANGER-WD03

WARNING: Be sure to fit the windshield on the vehicle prior to removing protective film to make sure a good fit. Once protective film is removed the windshield cannot be returned for refund.

1. Be sure to read these instructions thoroughly before opening and installing the 2002-2008 Polaris Ranger Lexan Windshield.
2. Check over the parts included in the cartons with the parts list shown below:

1 ¾" Loom Clamps	8 each
1 ½" Loom Clamps	2 each
1" Stainless Steels Bolts	14 each
1 ¼" Stainless Steels Bolts	4 each
Stainless Steel Washers	32 each
Stainless Steel Lock Nuts	8 each
Plastic Thumb Nuts	8 each
Stainless Steel Nuts	4 each
Rubber Gasket	1 each
Upper Lexan Brace	1 each
Lower Lexan Brace	1 each
Lexan Windshield	1 each

3. Start by pulling it out of the box and find a clean area to lay it down and install the hardware. Next take the rubber gasket and starting at one end firmly place along entire bottom edge of the Windshield. You will need to peel back the protective film from the edge to install the gasket. If you leave the bulk of the protective film on while installing you can keep from scratching the windshield.
4. Next take the upper and lower Lexan braces and install them on the windshield. You will notice that one of the braces is shorter; this is the top brace and will go on the outside of the windshield at the top of the windshield. The bend will be above the bolts when installed. The bottom brace will go just below the hinge on the inside of the windshield. As before the bend will be above the bolts, when installed the brace should look like a shelf pointing towards the rear of the vehicle. See Fig. 1 for a visual explanation.




Fig.

1

5. Now you are ready to place the windshield on the Ranger and attach to the roll cage. NOTE: THE BEND IN THE TOP OF THE WINDSHIELD SHOULD GO BELOW THE TOP TUBE. Fig. 2 shows the proper placement for the hardware. Install the clamps as shown for the top two slots in the windshield only. Use the 1" bolts for this application.




Fig. 2

6. Now install the clamp for the slot right above the hinge. You will use the 1 1/4" bolts for this. Fig. 3 illustrates how this is installed. You will have some of the bolt sticking out towards the front of the vehicle. This is to hold the bottom section of the windshield when it is in the raised position. You will use the same thumb nut for the raised and lowered positions.




Fig. 3

7. Finally install a clamp around the tube below the hinge as shown in Fig 4. You will use the 1 ¼” bolts here. This clamp holds the bottom of the windshield down. See also Figs 5 & 6.




Fig. 4

8. Enjoy, and remember- when cleaning the windshield do so gently at first with warm water and mild detergent to dislodge any grit that may scratch the Lexan. After rinsing and drying with a soft cloth, you may then polish the windshield with an appropriate commercially available plastic polish, also available from Mammoth Designs. This will ensure many seasons of clarity and keep scratching and swirling to a minimum. Never use cleaners such as Windex that contain ammonia as doing so may adversely affect the windshield.
9. If needed, additional Velcro sets are available, as well as other spare parts and

hardware. Contact Mammoth Designs for information.

10. Transporting or trailering your UTV with the windshield installed is not generally recommended. It is best to remove the windshield before transporting your UTV. **Thank you for your purchase!**




Fig. 5




Fig. 6

Over Armour Offroad
2515 Bypass Rd, Flemingsburg, KY 41041
Phone: 606-845-7439 or 606-748-5136

If for any reason you choose to return this product it must be returned within **30 days from date item is received**. You **MUST** package the product exactly **as it was originally packaged from the factory to get a full refund for the product!** The vinyl windows should never be folded when packaging in the box or for storage purposes. Lay all the windows on top of each other with the canvas folded in between and the paper (if available) on both sides of the windows.

All returned products will be inspected upon arrival at the production facility and must be in unused, factory new condition to receive refund - a 20% restocking fee will apply.

If ordered from Mammoth Designs please call at 606-845-2227 to gain a return authorization number, use our preferred shipping carrier (UPS) to return the item (unless the item is defective, you are responsible for paying the shipping to return the item.) **Any returns submitted to Mammoth Designs without a return authorization number will be charged a 20% restocking fee.** If ordered from one of Mammoth Designs many distributors', you must first call them and see what their return policy is. Once your item reaches our production facility, our customer satisfaction team will inspect your item to ensure unused, factory new condition. **NOTE: All Lexan windshields must be returned with the original protective film intact and not removed. Do NOT REMOVE if you have any intentions of returning the item. Refund/ replacement on lexan windshields will only be processed on items with original protective film or if the windshield is defective.**

Items must be properly packaged in the original shipping carton to protect them during transit and ensure your returned item arrives back factory fresh, and in new resalable condition (**any returned items that have been used, altered or damaged in any way will not be subject for a refund.**) All contents including instruction manuals, accessories, hardware, Velcro, etc. must be included in your return shipment. Only items in OEM factory new condition will be approved. Once returned items are received, credit will be issued to the original credit card/ payment method used for the purchase. Outbound shipping and return shipping cost will not be refunded. Please allow 4 to 6 weeks for your refund to be processed.



To The Owner of this Product:

Thank you for purchasing one of Over Armour Offroads Enclosure &/or Windshields! Below are the terms under which your product is covered under our manufacturer's warranty.

30 Day Warranty which includes and is not limited to replacing the enclosure and/or windshield due to defect of the product. Please refer to the return policy in this case for more information.

1 Year Warranty includes any defect in material or workmanship within this time frame we will gladly correct the problem or replace the enclosure &/or windshield. Upon submitting for the correction or replacement we will need to receive pictures of the defect in material or workmanship along with the receipt from the date of purchase.

Thank you,

Over Armour Offroad
www.overarmouroffroad.com