

Defender LT Front Bumper, Polaris RZR® XP 1000 (14-18) Instructions

hmfracing.com/equipment/polaris-rzr-xp-1000/defender-lt-front-bumper-polaris-rzr-xp-1000-14-

Removal

1. Remove the **Winch Cover** from the **Front Fascia**.

Installation

1. Using the (5) supplied M8 hex bolts, (10) washers, and (5) nyloc nuts, install the **IQ Defender Front Bumper**.



2. Carefully center the bumper, then tighten the mounting hardware.













3. Use the (4) supplied M6 button head bolts with (4) washers to install the **skid plate**.



4. Speed nuts are preinstalled on the skid plate mounting tabs.

Discussion

Hardware

-  (4) Bolt - Buttonhead - M8-1.25 X 20
-  (3) Bolt - Hex - M8-1.25 X 20
-  (2) Bolt - Hex - M8-1.25 X 25
-  (5) Nut - Nylock - M8-1.25
-  (4) Nut - Speed/Clip - M8-1.25
-  (1) Skid Plate, Polaris® XP 1K / Turbo / S900/1K , LT Front Bumper
-  (12) Washer - Flat - 1/4"
-  (2) Washer - Flat - 3/8"

* Click thumbnails to enlarge

© Copyright 2020, HMF Engineering • 5111 West 164th Street • Brookpark, Ohio 44142

[terms](#) [privacy](#) 