

# Defender Rear Bumper, Can-Am® Maverick Sport Instructions

 [hmfracing.com/equipment/can-am-maverick-sport/defender-rear-bumper-can-am-maverick-](https://hmfracing.com/equipment/can-am-maverick-sport/defender-rear-bumper-can-am-maverick-)

## Installation

1. Install the bumper on the vehicle by sliding it into place through the stock cutouts in rear plastics.
2. Use the supplied **(4) M8x25 Allen head bolts, (8) ¼" washers** and **(4) Nylocs** to bolt the **two upper brackets** of the bumper to the holes in the frame of the vehicle. **DO NOT TIGHTEN.**



3. Install the **(2) M8x25 Hex Bolts, (4) ¼" washers** and **(2) nylocs** to the lower portion of the vehicle's frame.





4. Center and level the bumper then tighten the upper four bolts then the lower two.



## Discussion

---

## Hardware

---

-  (4) Bolt - Allen - M8-1.25 X 20
-  (2) Bolt - Hex - M8-1.25 X 16
-  (6) Nut - Nylock - M8-1.25
-  (12) Washer - Flat - 1/4"

\* Click thumbnails to enlarge

© Copyright 2020, HMF Engineering • 5111 West 164th Street • Brookpark, Ohio 44142

[terms](#) [privacy](#) 