


Defender U4 Front Bumper, Polaris RZR® XP 1000 (14-18) Instructions

 hmfracing.com/equipment/polaris-rzr-xp-1000/defender-u4-front-bumper-polaris-rzr-xp-1000-14-

Installation

1. Remove the stock grill fascia and the stock winch cover.
2. Install the supplied (2) 1 ½" bar clamps using the supplied (8) m8x25 hex (16) ¼" washers (8) nylocks









3. Using the (5) supplied m8 hex bolts, (10) ¼" washers, and (5) nylocks, install the front bumper.
4. Tighten all of the bolts and install the stock grill fascia.
5. Inspect all of the areas around the bumper for proper clearance and alignment, and adjust as necessary.

Discussion

Hardware

-  (2) Bolt - Hex - 3/8-16 X 1"

-  (5) Bolt - Hex - M8-1.25 X 20
-  (8) Bolt - Hex - M8-1.25 X 25
-  (2) Clamp - U4 (set)
-  (2) Nut - Nylock - 3/8"-16
-  (13) Nut - Nylock - M8-1.25
-  (26) Washer - Flat - 1/4"
-  (4) Washer - Flat - 3/8"

* Click thumbnails to enlarge

© Copyright 2020, HMF Engineering • 5111 West 164th Street • Brookpark, Ohio 44142

[terms](#) [privacy](#) 