



Sport Rear Bumper Instructions (P187P361)

NOTE: Prior to installation, please verify if a revised version of this instruction sheet is available on proarmor.com.



Remove rear fascia bolts, two upper & two lower bolts (4-bolts).



Remove rear fascia from vehicle.



Remove the 2 M6 bolts holding the muffler support bracket to the chassis, on each side of the vehicle.



Place the bumper onto the car and line up the mounting brackets to the chassis. You may need to work the lower mounting brackets around the radius rod plate by angling the bumper as you put it place.



Reinstall the 2 M6 bolts to secure the upper mounting tabs.



TURBO S MODELS ONLY: Apply Spacer bracket to lower mouhting bracket.



Sport Rear Bumper Instructions (P187P361)



The supplied M10 bolts and winged nuts will be used to fasten the lower mounting brackets of the bumper to the chassis. The winged nut will allow you to tighten the M10 bolts without having to hold the nut on the other side, since space is very limited between the chassis mounting area and rear differential.



Adjust the bumper so that it is level. Once you are satisfied with the placement of the bumper, fully tighten all of the hardware. Re-attach the rear fascia. Torque down all bolts applied. Install is now complete. Make sure all hardware is properly secure before and after every use of vehicle.





AWARNING

- Never stick hands, head or arms outside of vehicle at any time when it is in motion.
- **Always** wear and use proper safety equipment when using any Pro Armor product.
- Improper use of directions and/or product can result in injury to yourself or damage to your vehicle.
- **Disclaimer please read:** This product is sold without warranty expressed or implied. No warranty or representation is made as to the products ability to protect the user / occupant from any injury or death in any manner of use. The user assumes that risk. The effectiveness of this equipment is directly related to the manner in which it is installed, used, and / or maintained.

Proper installation is solely the responsibility of the installer, and will not be assumed by Pro Armor.

If you have questions about your installation or are unable able to complete installation, contact Pro Armor Customer Service (888)312-7667 or have an
authorized dealer or trained technician, inspect your installation.