

# Over Armour Offroad

2515 Bypass Rd. Flemingsburg, KY 41041

606-845-7439

## Instructions for Installation and Care of 08-09 Polaris Ranger Crew Full Cab With Vinyl Windshield

PO-08&09Crew-FC01

**Notice: Do not smoke inside the cab or expose the enclosure to direct flames. Cab is Flammable.**

1. Be sure to read these instructions thoroughly before opening and installing the Polaris Ranger Crew Cab Enclosure. The installation is best done when the temperature is 70 degrees F. or warmer. This is to help the adhesive Velcro to stick better. If installation must be done in colder temperatures it will help to warm the Velcro strips prior to installation.
2. Carefully open the carton and remove the rolled up Cab Enclosure on a large flat surface that is clean and free of dirt or other material that may soil or scratch the windows of the Cab.
3. It will help to raise the bed prior to installing the cab enclosure


4. Check over the parts included in the carton with the parts list shown below:

2" Velcro Hook strips:	4 each	6" long
"    "	6 each	10" long
"    "	1 each	58" long
1" Velcro Hook strips:	1 each	30" long
"    "	2 each	14" long
Snap studs	25 each (1 extra)	
Cab Enclosure	1 each	

5. Before putting the Full Cab over the roll cage there are several pieces of adhesive Velcro that should be installed first. To start with raise the bed and place the 58" adhesive Velcro strip centered along the bottom of the cage on the flat metal strip. Next open the front hood of the Crew and prop it up with something or have someone hold it up. Across the bottom of the dash you will be placing the 30" (1" wide) and 2 10" (1" wide) strips as shown in the photos below.



6. Now loosely drape the Cab Enclosure over the Ranger Crew roll cage. While having someone holding the hood up or propping it up, slip the middle nosepiece between the hood and dash and attach it to the adhesive Velcro underneath the dash. Next pull the side nosepieces under the dash and attach to Velcro there. Finished look should be like photos below.



7. Now note the positions for the two 10" tabs on either side of the windshield. Attach the coordinating adhesive strips to the inside of the roll cage.
8. Working your way to the rear of the roll cage, carefully fit the Cab into position. Be sure to pull the lower edge of the rear panel down between the rear of the roll cage and the front of the dump bed. Apply the 58" Velcro Hook strip here.
9. Next match up the remaining Velcro strips with the appropriate tabs and attach. Anywhere there is a double-sided Velcro strip sewn to the cab it will wrap around the roll cage as shown in the photos below.



10. Mark the desired locations for the stud snaps on the fenders and side panels. Then install the stud snaps to the Ranger using only a #2 Phillips screwdriver.

11. To open and stow the doors, move the zipper fully rearward and fold the bottom portion of the doors up and attach to the two hook and loop strips. Then begin to form a vertical roll with the door by rolling it inward from the front edge toward the rear of the door. Secure in place using the two hook and loop straps provided. Try to form a roll approximately 2” in diameter to assure that the door will not stick out very far while stowed.

#### Cleaning and Storage Recommendations:

1. Before removing the Mammoth Cab for storage, make sure it is very clean in order to prevent scratching of the window panels. Clean with a soft rag or sponge using a mild liquid detergent soap and warm water solution. Never rub the windows with a dry cloth or rag! Let the Cab dry thoroughly before attempting to roll for storage.
2. It is important that the Cab be rolled up for storage rather than folding. Folding will cause damage to the windows!!! Carefully roll up the Cab similar to the way it was when it was packed at the factory. On a large, clean and flat surface, fold the doors over the rear panel first, then, interleave the top and windshield on top of the doors. Begin rolling the Cab into a roll approximately 8 inches in diameter. Put the rolled Cab back into the carton for storage at a normal room temperature. It is best not to expose the Cab to either extreme hot or cold temperatures when storing.
3. A special cleaner conditioner is available from Over Armour Offroad that will greatly increase the service life of the Cab Enclosure. In addition, if additional hook and loop sets are needed, they can also be ordered.

## Finished Installation



## Return Policy

If for any reason you choose to return this product it must be returned within **30 days from date item is received**. You **MUST** package the product exactly **as it was originally packaged from the factory to get a full refund for the product!**

The vinyl windows should never be folded when packaging in the box or for storage purposes. Lay all the windows on top of each other with the canvas folded in between and the paper (if available) on both sides of the windows.

**All returned products will be inspected upon arrival at the production facility and must be in unused, factory new condition to receive refund - a 25% restocking fee will apply.**

If ordered from Over Armour Offroad please call at 606-845-7439 to gain a return authorization number, use our preferred shipping carrier (UPS) to return the item (unless the item is defective, you are responsible for paying the shipping to return the item.) **Any returns submitted to Over Armour Offroad without a return authorization number will be charged a 20% restocking fee.** If ordered from one of Over Armour Offroads many distributors', you must first call them and see what their return policy is. Once your item reaches our production facility, our customer satisfaction team will inspect your item to ensure unused, factory new condition. **NOTE: All windshields must be returned with the original protective film intact and not removed. Do NOT REMOVE if you have any intentions of returning the item. Refund/ replacement of a windshield will only be processed on items with original protective film or if the windshield is defective.**

Items must be properly packaged in the original shipping carton to protect them during transit and ensure your returned item arrives back factory fresh, and in new resalable condition (**any returned items that have been used, altered or damaged in any way will not be subject for a refund.**) All contents including instruction manuals, accessories, hardware, Velcro, etc. must be included in your return shipment. Only items in OEM factory new condition will be approved. Once returned items are received, credit will be issued to the original credit card/ payment method used for the purchase. Outbound shipping and return shipping cost will not be refunded. Please allow 4 to 6 weeks for your refund to be processed.

## Warranty

To The Owner of this Product:

Thank you for purchasing one of Over Armour Offroad Cab Enclosures, Tops &/or Windshields!  
Below are the terms under which your product is covered under our manufacturer's warranty.

30 Day Warranty which includes and is not limited to replacing the enclosure, tops and/or windshield due to defect of the product. Please refer to the return policy in this case for more information.

1 Year Warranty includes any defect in material or workmanship within this time frame we will gladly correct the problem or replace the enclosure, tops &/or windshield. Upon submitting for the correction or replacement we will need to receive pictures of the defect in material or workmanship along with the receipt from the date of purchase.

Thank you,

Over Armour Offroad  
[www.overarmouroffroad.com](http://www.overarmouroffroad.com)