

# Slip On Exhaust Instructions

For Models: Sportsman\* 400 (2004-2014), Sportsman\* 500 (2002-2013)

#### Removal

- 1. Remove the Nuts, Carriage Bolts and Grommets from the Stock Silencer.
- 2. Using a Spring Puller or a Long Piece of Electrical Wire (recommended), remove (2) **Springs** holding the **Silencer** to the **Head Pipe**. Remove the **Silencer**.
- 3. Remove the Silencer Bracket Bolts and Bracket.
- 4. Remove the Left-Rear-Sub-Frame-Bolt.

## Installation

- 1. Check the original gasket for wear or damage. Replace if necessary.
- 2. Position the **HMF Slip On** so the **Mounting Brackets** line up with the **Rear-Most-Sub-Frame-Bolt-Holes**, and the **Inlet** lines up with the **Head Pipe.** (See Figure #1)
- 3. Use the original bolts to mount the **Silencer** to the **Sub-Frame**.
- 4. Using a spring puller or a long piece of electrical wire (recommended), install the (2) **Supplied Springs** at the **Inlet-to-Head-Pipe-Joint**.
- 5. Inspect all areas around the exhaust for proper clearance with hoses, plastics, etc. Adjust as necessary.

**HMF Turn Down Installation** (See Figure #2)

- 1. Remove the (4) Allen Head Bolts from the Swamp End Cap and remove the End Cap.
- 2. Slide the Swamp Turn Down Adapter Tube through the End Cap so the flanged end will butt up to the Silencer.
- 3. Replace the **End Cap** (with adapter tube) and (4) **Allen Head Bolts.**
- 4. Slide the **Clamp** over the **Turn Down** and slide the **Turn Down** over the **Adapter Tube.**
- 5. Tighten the Clamp.

Note: HMF will not be held responsible for damages caused by improper installation.

### Hardware

- \*\*
- (1) 400005 90005100C
- F
- (1) 400253 Outlet | Turn Down Snorkel

#### Stainless

(1) 6950096 - Spark Arrester | 2 in Standard

#### Assembly

- ř
- (2) 400076 Spring(s) Long Neck
- (1) 400189 Turn Down Adapter 2-1/2 in

Figure #1



Figure #2



(1) 90005100C



(1) Outlet | Turn Down Snorkel Stainless



(1) Spark Arrester | 2 in Standard Assembly



(2) Spring(s) - Long Neck



<sup>\*</sup> Click thumbnails to enlarge

# (1) Turn Down - Adapter - 2-1/2 in

