

# PRO ARMOR

EVERY RIDE HAS A STORY



POLARIS XP1000

ROLL CAGE REAR BUMPER SKID PLATE (P141P362)

## INSTALLATION INSTRUCTIONS

**WARNING**

Make sure to read instructions carefully. Do not proceed to install if any parts or hardware are missing. Doing so may cause damage to your vehicle.

**APPROXIMATE INSTALL TIME: 10 MINUTES (1-2 PERSONS)**

**PARTS LIST:**

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	P141P362-02	PRE-PACKAGE ASSEMBLY	1
2	P141P362HDW	HARDWARE KIT	1



#### HARDWARE LIST:

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	5258479	CLAMP-ROOF, RZN4, BLK	4
2	HDWN0008	NUT, M6 X 1.0 NYLOC FLANGED HEX	4
3	HDW00143	1/8"ADHESIVE BACKED FOAM RUBBER 3/4" WIDE_1"	4
4	HDWB0251	BOLT, M6 x 16MM, BUTTON HEAD FLANGE, BLACK ZINC	4
5	HDWW0026	1/4" NYLON FLAT WASHER, BLACK, OD .74"	4

#### INSTALLATION:

1. Prepare the supplied half clamps by placing a strip of the supplied adhesive foam to the inside surface.



2. Have a helper hold the skid plate to the rear bumper while you secure it using the half clamps with the supplied hardware. Make sure the nylon washer is placed between the half clamp and nyloc nut. Hand tighten only.





3. When all 4 clamps are in place, adjust the skid plate so that it is centered on the rear bumper. Once you are satisfied, torque all bolts down. Install is now complete.

[For further information on installation instructions and warnings please visit our website [WWW.PROARMOR.COM](http://WWW.PROARMOR.COM) or contact customer service at 1-888-31-ARMOR.]