



Skid Plate, Polaris® Sportsman/Scrambler XP 850/1000 Instructions

Installation

1. Remove your current skid plate from the machine. *(See Figure #1)*

(See Figure #2)

2. Position the Replacement Skid Plate on the bumper mounting locations and use the supplied hardware to mount the skid plate to the bumper. *(See Figure #3)*

(See Figure #4)

3. Check to ensure the skid plate is level and tighten hardware.

Hardware

-  (4) 400184 - Bolt - Buttonhead - M8-1.25 X 25
-  (4) 400015 - Nut - Nylock - M8-1.25
-  (8) 400073 - Washer - Flat - 1/4"

* Click thumbnails to enlarge

Figure #2



Figure #4



Figure #1



Figure #3



(4) Bolt - Buttonhead - M8- 1.25 X 25 (4) Nut - Nylock - M8-1.25 (8) Washer - Flat - 1/4"

