


- Do not discard packaging until product has been successfully installed.
- SuperATV does not recommend keeping Windshield installed while transporting on an open air trailer. Remove or secure with straps.

Item	Description
A	Upper Bracket
B	Windshield
C	Right Nut Bracket
D	Right Swing Bracket

Item	Description
E	Left Nut Bracket
F	Left Swing Bracket
G	Lower Frame



(kit contents continue on following page)

Need help with your installation?


✉ sales@superatv.com 💻 www.superatv.com

☎ 1-855-743-3427 🕒 8:00am - 8:00pm EST M-Th
8:00am - 7:00pm EST Friday
9:00am - 2:00pm EST Saturday


Read instructions and view illustrations before beginning.

Thank You
For Choosing
SUPERATV.COM[®]


(kit contents continued)




separate Clamps and set aside



separate components shown from Wiper and set aside




- If applicable, raise front of Roof.




To ease installation, soak Bulb Seal in hot water before cutting or installing to increase flexibility.

- Install provided Bulb Seal to Lower Frame (G).




- Install provided Foam to locations shown on inside of Windshield (B).





- Install provided D-Seal to location shown on Windshield (B).





- Install Left and Right Nut Brackets (E)(C) to Windshield (B) with hardware shown; tighten.



- Install Right Swing Bracket (D) and Lower Frame (G) to Hinges on Windshield (B) with hardware shown; tighten.
- Repeat for Left Swing Bracket (F) installation.




- Install Thumb Screw and Bushings; tighten.
- Repeat for opposite end.




Once installed, set Swing Brackets to position shown and tighten Thumb Screws.

- Install Flat Seal across Windshield.
- Trim ends to match Windshield (B).
- Poke corresponding holes in Windshield (B) through Flat Seal.


Do not install if machine is equipped with a stock Roof.



- Insert Grommets into holes in Windshield (B).
- *Tip; apply soapy water to Grommets before installing.*
- Install Inserts into Grommets.





- Place Windshield assembly onto machine.



- Place Clamps around Cage in locations shown.
- Repeat for passenger side.




These steps are for machines with a SuperATV Roof installed:




- **These steps are for machines with a SuperATV Roof installed.**

- **See following page for machines with a stock Roof installed.**

- Secure Windshield (B) and Upper Bracket (A) to Brackets on SuperATV Roof with hardware shown.
- Secure Clamps to Windshield (B) with previously removed Clamp hardware.
- Tighten all hardware.




- Install Plug into Windshield (B).




stock Roof installed:

- Install Upper Bracket (A) to Windshield (B) with hardware shown; tighten.
- Install Bulb Seal to Upper Bracket (A).
- Secure Clamps to Windshield (B) with previously removed Clamp hardware; tighten.




- Resecure stock Roof.


install previously removed Wiper components to Frame



install Wiper and Handle; do not tighten completely



SuperATV recommends positioning Handle and Wiper as shown; tighten completely



- Lower Frame can be used as a vent. Loosen Thumb Screws, set desired opening, and re-tighten Thumb Screws.



- When removing Hood, remove Thumb Screws and Bushings and place Lower into position shown.



Liability Statement

SuperATV's® products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SuperATV® and is not recommended. SuperATV's® products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV® to verify that they will work together.

Although SuperATV® has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV® urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV® products, user agrees that should damages occur, SuperATV® will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV®, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV®. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV® will warranty only parts provided by SuperATV®. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by SuperATV®. SuperATV® parts and products are not warrantied if item was not installed properly, misused, or modified.

Installing, adding, modifying, or fabricating any factory or aftermarket product to your ATV/UTV may violate certain local, state, and federal laws. Be advised that laws vary depending on town, city, county, state, etc. Use of certain products on public streets, roads, or highways may be in violation law. The Buyer is solely and exclusively legally and personally responsible for any violation of the law by the installation or use of the product. You must abide by all local, state, and federal laws, including but not limited to vehicle safety, traffic laws, and ordinances. It is your responsibility to know the laws and how they apply to you.

The Buyer is responsible to fully understand the capability and limitations of his/her vehicle according to manufacturer specifications, warnings and instructions and agrees to hold SuperATV® harmless from any damage resulting from failure to adhere to such specifications, warnings and/ or instructions. The Buyer is also responsible to obey all applicable federal, state, and local laws and ordinances when operating his/her vehicle while using this product, and the Buyer agrees to hold SuperATV® harmless from any violation thereof.