

## KAWASAKI® MULE™ PRO FX/FXT™ BENCH SEAT COVER

- Remove front seat bottom and tilt back seat bottom (FXT) forward.
- Seat backrests are more narrow than seat bottoms and are the same for front and rear seats.
- Pull elasticized cover around front seat bottom and attach Velcro® straps. Repeat for seat back rest noting top of cover has the Velcro strap that mates to bottom of seat cover.
- Pull elasticized cover around rear seat bottom. Attach Velcro® straps.
- Rear seat back rest is installed by stretching cover around seat allowing elastic to stretch around seat and make a smooth tight fit. Attach Velcro straps.

Your new seat covers are guaranteed against any defects in material and workmanship for one year from the date of purchase. Should any problems arise, please contact your dealer. No warranty card is necessary. Side bar pads shown in image are available from us but are not included with seat covers.

**WARNING:** Prolonged exposure to direct sunlight may result in fading and/or tendering of the material. Do not store your Mule with seat cover installed in direct sunlight. Damage resulting from exposure to direct sunlight cannot be warranted.

Your ATV/UTV has several warning and caution labels around the machine that may be covered when these covers are installed. It is your responsibility as the ATV/UTV owner to read and understand these warnings as well as making sure anyone who rides the ATV/UTV are aware of the proper operation.

